



SMARTOSCOPE VARIO II

INSTRUCTIONS FOR USE

VARIO II ADAPTER PARTS



1. Open the phone clamp (C) using the clamp adjustment knob (E) and insert your smartphone in to the adapter, your camera lens should be on the opposite side from the strap eyelet (G).



2. Set the height of the phone clamp (C) to securely hold your smartphone model in the adapter by turning the clamp adjustment knob (E), turning clockwise lowers the clamp, turning anti-clockwise raises the clamp.



3. Loosen the locking wheel (A) and then rotate the Opticsrail (I) so that the hole sits central over the lens of your smartphone camera. If your smartphone has multiple lenses - simply align the hole with the lens you want to use.



4. Once alignment has been achieved, secure the Opticsrail (I) by turning the locking wheel (A) clockwise until it is secured in place.



5. The standard included Opticsrail* (I) features a mounting thread to accept adapter rings with a 30mm thread. Attach your selected adapter ring by screwing it in to the mounting thread (J) on the Opticsrail (I)



6. Push the adapter ring on to the eyepiece of your optic and secure.



7. To remove or change the opticsrail, unscrew the locking wheel (A) so that the opticsrail is released. Replace with your chosen opticsrail and insert the locking wheel, turn clockwise to tighten.

AVAILABLE ADAPTER RINGS (SOLD SEPARATELY)

We offer a wide range of push-on eyepiece rings compatible with:
Kowa, Swarovski, Leica, Zeiss, and Focus scopes.



Visit www.kowaoptic.com for the full list of available adapter rings.